

## SICHERHEITSHINWEISE

DE

### Smart Mover - Rangierschiene

### Easy Fix - Transportständer

Bitte lesen Sie die Sicherheits- und Montagehinweise sorgfältig durch. Die Nichtbeachtung der Hinweise kann zu Sach- und/oder Personenschäden führen.

Die Motea GmbH übernimmt keine Haftung für Sach- und/oder Personenschäden, die durch eine unsachgemäße beziehungsweise mangelhafte Montage oder Nutzung entstehen. Irrtümer und Änderungen vorbehalten.

- ✓ Prüfen Sie den Lieferumfang auf Vollständigkeit und sichtbare Beschädigungen.
- ✓ Überprüfen Sie vor jedem Gebrauch die korrekte Funktionsweise.
- ✓ Die maximale Traglast darf nicht überschritten werden (max. 450 kg).
- ✓ Nur auf ebenem, festem & tragfähigem Untergrund verwenden.
- ✓ Kontrollieren Sie im Vorfeld, ob die Radwippe und die Rangierschiene für ihr Fahrzeug verwendet werden kann.
- ✓ Sichern Sie Ihr Fahrzeug gegen Umfallen. Nicht am Fahrzeug ziehen oder anlehnen.
- ✓ Sichern Sie die Motorradwippe gegen Verrutschen.
- ✓ Gefahrenbereich sofort verlassen, wenn das Fahrzeug zu kippen droht.
- ✓ Prüfen Sie die Schraubverbindungen in regelmäßigen Abständen und ziehen Sie diese bei Bedarf nach.



## SAFETY INSTRUCTIONS

EN

### Smart Mover - Dolly Mover

### Easy Fix - Wheel Chock

Please read the safety- and installation instructions carefully. Non-observance can lead to material damage and/or personal injury.

Motea GmbH accepts no liability for damages caused by improper and faulty installation or use. Modifications and errors reserved.

- ✓ Check scope of content for completeness and possible damages.
- ✓ Before each use, check correct functionality.
- ✓ Do not exceed the maximum load capacity (max. 450 kg).
- ✓ Only be set up on horizontally level ground with a sufficient load capacity.
- ✓ Check if your vehicle can be used with the dolly mover and wheel chock.
- ✓ Secure your vehicle against falling over. Do not pull on or lean against the vehicle.
- ✓ Secure vehicle against slipping or rolling away.
- ✓ Clear area if vehicle is in danger of falling.
- ✓ Check the screw connections regularly and retighten them if necessary.

